



*PREMIUM*

## **Braided Stainless Steel Hose**

*For Use w/ Premium Discrete Breather System*

### **INSTRUCTIONS**

(Please read entire sheet before beginning install)

#### **Parts included:**

1- 2', 4', 6' or 8' Length of Braided Stainless Steel Hose

#### **General Information:**

1. Both ends of the hose come with blue painters tape wrapped around the ends to prevent the SS Braid from unraveling.
2. We recommend leaving it on until you are ready to secure the hose with a hose clamp. If you are using the Chrome Cover Hose Clamp, then you can leave the tape on under the cover. This will help keep the braid from unraveling when slipping the cover on.
3. Before cutting the hose, we recommend using some painters tape or masking tape over the spot where you will be cutting. This will help keep the braid intact. We do NOT recommend electrical tape, it can get messy.
4. To cut the hose we recommend a hose cutter or a bolt cutter, a good pair of tin snips will also work.. We do NOT recommend a hack saw.
5. The SS Braid will withstand as much heat as your engine can generate, but the rubber hose inside, although it is high temp, it will lose integrity if it is touching something (top end of the engine or exhaust) that is 350\* F or hotter. Also, the SS Braid will scratch Paint, Powder Coat and Chrome. It will also cut through wires & wire sheathing. Make sure to route the hose so it is not touching the engine, exhaust, wires or anything else you do not want it to chaff through or scratch.

[www.DKCustomProducts.com](http://www.DKCustomProducts.com)