



CYCLONE COVER INSTRUCTIONS

MADE IN THE USA!!

These instructions are CRITICAL to read and follow. It is easy to ruin your New Cyclone Cover with an incorrect installation.

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1- Transparent Cover (with a protective covering)
- 1- Inner Cyclone "cage" (Black)
- 1- Outer Cyclone "cage" (Polished Aluminum or Black)
- 3- "cage" fasteners
- 1- Inner "cage" fastener

Installation Steps for Cyclone Cover:

1. Carefully remove the protective covering from both sides of the cover. This can be tricky, if only the outer layer starts coming off, begin in a new spot. Peeling it off slowly has best results. Do NOT use anything that may scratch the surface.
2. Install the inner cage cover to the backplate, the outside edge of the inner cage seals against the air filter element. Align the spokes of the cage to the desired "look" and tighten down to 18-24 Inch-lbs of torque.
3. Place the outer cage against the transparent cover and put the three remaining fasteners through both the outer cage and the cover. Line it up with the inner cage and tighten the fasteners to 18-24 Inch-lbs.

General Notes:

With the Cyclone Cover a whole new opportunity for personalization exists. You can paint, engrave, use decals, and whatever else you can imagine to the backplate that is now visible through the cover.

Important Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- **Blue Thread locker (medium) MUST be used on all threads. Not doing so risks serious damage to your engine. Not using Thread Locker could result in death or serious injury.**
- **Torque Values are in Inch-lbs (Not ft-lbs)**
- Care of the Transparent Cover: Use only mild detergents, with NO abrasives, along with a soft cotton cloth or microfiber.