



PREMIUM

BILLET M8 SOFTAIL TANK LIFT KIT

Made in the USA!

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

- 2 Billet Lift brackets (Black or Machine Cut)
- 2 Stainless nuts
- 2 Stainless washers
- 1 $\frac{3}{8}$ x 5" Frame Bolt
- 1 $\frac{3}{8}$ Nut

Installation Steps:

1. Remove Seat
2. Loosen rear tank bolt(s). (do not remove)
3. Remove front tank bolt(s). Keep washer(s) & acorn nut, they may be used with the tank lift kit.
4. Carefully raise the front of the tank up and follow fitment note below*
After you have verified fitment/made any necessary adjustments continue the install.
5. After lifting the tank up, remove the plastic trim pieces off of each tank ear. You will not use them when having the tank lift installed.
6. If some wires are restricting the tank from being raised, gently pull them (do not yank) to get enough slack.
- 7a. Mount each bracket to tank ears with the threaded end of the bracket facing the backbone. Install 1 washer between tank ear and nut loosely on each side. A washer is not needed between the tank ear and tank lift bracket, if you do put a washer between the Tank Ear and Tank Lift bracket, make sure to put a washer between the lower part of the tank lift and the frame to keep the spacing equal.
- 7b. Lower the tank down until the bottom of the tank lift bracket holes match up with the factory tank mounting holes. (When lowering the tank, pay extra attention to the threads near the backbone. If it appears the threads will contact the backbone, your tank ears may be toed in slightly. To correct this you need to slightly pull each tank ear away from the backbone until the tank lift threads will not contact the backbone. You may also need to put a couple of washers between the bottom of the tank lift bracket and the factory tank mounting holes.)
8. Install the provided $\frac{3}{8}$ x 5" Frame bolt through the lower holes in the tank lift brackets. Snug

the nut up on this bolt, but do not tighten all the way.

9. Tighten the top two nuts completely.

10. Tighten the 3/8x 5" Frame Bolt.

11. Tighten the rear tank bolt.

12. Install seat and go for a ride!!!

***Important Fitment Note:**

If you did not check before ordering, Please make sure this mod does not interfere with any other mods/components on your bike - like trees, forks, handlebars, etc.

We are NOT responsible for any damage done to your bike because of the kit.

It is easy to check for clearance:

If your tank ear is under your triple tree you will not be able to lift your tank. You can see pictures of Tank ears that are compatible and pictures of tank ears that are not compatible below.

1. With bike on kickstand, take the bolt(s) out of the front of your tank.

2. Loosen (do not remove) the bolt(s) at the rear of your tank.

3. Turn your handlebars all the way to the left and raise the tank up X inches to check for clearance issues.

4. Turn your handlebars all the way to the right and raise the tank up X inches to check for clearance issues.


General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- Use blue (medium) thread locker on all threads at the front of the tank.
- Installing this tank lift will result in a slight weight distribution change on your bike.
- Steering may feel a bit quicker. Exercise caution as you get accustomed to the slightly higher center of gravity.
- Be aware that your gas gauge may read differently with the tank at a different angle.
- If you have the Machine Cut Finish, as little as 15 minutes with some chrome polish or other slightly abrasive metal cleaner will produce a mirror finish.

www.DKCustomProducts.com

Patented

Compatible



Not Compatible

