



NDW STYLE SHIFT PEG

Fits All Harley's & Most other Motorcycles

INSTRUCTIONS

Parts included:

- 1 NDW Style Shift Peg
- 1 Bolt

Installation Steps:

1. Remove existing shift peg
2. Install NDW Shift Peg with stock bolt or included bolt
3. Adjust angle of NDW Shift Peg to your comfort (tighten snugly-HD:Torque spec 8-12 ft-lbs)
4. Go for a ride!

General Notes:

- The riders safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.
- HD Torque Spec: 8-12 ft-lbs.
- This peg can also be used as a Heel Rest or brake pedal. For a brake pedal, this will generally require cutting off existing brake pedal and tapping brake lever for bolt. Alternatively a hole can be drilled and a longer bolt and nut can be used to secure the new brake pedal.