



HANDLEBAR TOP CLAMP

Fits Most 1974-Up Sportster, Softail & Dyna Models

INSTRUCTIONS

Parts included:

- 1 Handlebar Top Clamp
- 4 Chrome Socket Head Plugs

Installation Steps:

1. Using stock bolts tighten top clamp down to where it is snug. Adjust handlebars to desired position.
2. Tighten rear bolts first to 12-18 ft-lbs. Then tighten front bolts to 12-18 ft-lbs.
3. Insert chrome plugs into hole on each bolt (where the allen wrench goes)

General Notes:

- The riders safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.
- Top Clamp Torque Specs- 12-18 ft-lbs.