



CHIN SPOILER for SOFTAIL

(won't fit the Heritage or Fatbob Fender)

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1 Chin Spoiler w/ Mounting hardware
- 2 Extra Zip ties

Installation Steps:

1. The Spoiler comes with a semi-gloss primer coat. You can run it how it is, or give it a light sanding and apply a couple of coats of your favorite rattle can paint. Or you can take it to an auto body shop or custom paint shop.
2. If you are going to paint the spoiler, it is highly recommended that you install the spoiler first, to verify fitment and perform any clearancing that may need to be done. It is unlikely you'll need to do any clearancing, but it always makes sense to trial fit any part before it is painted.
3. Remove the cushion clamps (P-Clamps) that are fastened to the lower mounting holes on your spoiler. Your spoiler is shipped to you with two pairs of zip ties, with the 'trial fit' ties already looped through the upper mounts, and the 'final install' ties wrapped in green tape.
4. We have found it is easiest to mount the spoiler by holding the spoiler in place and looping the upper zip ties around the bike's frame downtubes and then slipping the ties through their clasp mechanism. It may be easier to do this with a helper holding the spoiler in place while you capture the zip ties.

5. Spread the lower cushion clamps so they can be wrapped around the lower frame rails, and then reinstall the 1 inch button head bolts, using a flat washer between the bolt head and the chin spoiler surface.

NOTE: It is EXTREMELY important to use the flat washers between the bolt head and the chin spoiler or the bolt could be pulled through the chin spoiler when tightening.

6. Go for a Ride!

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue threadlocker be used on all threads.
- We are NOT responsible for any damage done to you or your bike as a result of the installation of this Spoiler.
- Won't fit the Heritage or Fatbob Fender
- After double checking everything - - Have fun! Go for a ride!!!

www.DKCustomProducts.com

Note: The user shall determine suitability of this product for his or her use. The user shall assume all risk for damage and liability to the vehicle and for compliance of any regulations and any incurred financial obligations due to vehicle inspections.