



CHIN SPOILER for Sportster

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1 Chin Spoiler
- 1 Mounting Bracket
- 3 Bolts w/ washers (bracket to spoiler)
- 2 Bolts (bracket to bike)

Installation Steps:

1. The Spoiler comes with a semi-gloss primer coat. You can run it how it is, or give it a light sanding and apply a couple of coats of your favorite rattle can paint. Or you can take it to an auto body shop or custom paint shop.
2. For 2004-Up models, unbolt the mounting bracket from the Spoiler, and bolt the mounting bracket to the frame. Then bolt the Spoiler back to the mounting bracket. Even if you are going to paint the spoiler, it is recommended to bolt it up first to see how it will fit.
3. For 1986 - 2003 models, two 5/16" holes need to be drilled in the cross-brace below the rectifier. Use the bracket holes as a template for the holes to be drilled in the cross-brace. Make sure they are level and even, otherwise the Chin Spoiler could end up mounting unevenly. You will need to get two longer bolts, with matching washers and nuts to attach the mounting bracket to the frame in the holes you drilled.
4. Go for a ride!

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue threadlocker be used on all threads.
- Torque all fasteners to 12-16 ft. lbs.
- These are adjustable as both mounting locations have adjustability. Make sure everything is lined up and fitting properly before final installation. IF you are having trouble try loosening the bolts at the mounting locations, adjusting the spoiler, then retightening all bolts.