



Convert Sportster Offset Footpeg Mount

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

- 1 Offset Mount Delete Kit
- 1 Hardware Kit

Installation Steps:

1. Remove both footpegs from the bike.
2. Remove the shift linkage from the stock footpeg mount on the left side of the bike.
3. Remove the shifter and footpeg mount assembly from the left side of the bike. (Reference your service manual if needed.)
4. Using the new hardware provided install your offset delete kit and stock shifter the opposite from the way it was removed.
5. Reinstall your shift linkage.
6. Remove the right side peg mount. (Reference your service manual if needed.)
7. Using the new hardware provided install your offset delete kit the opposite way it was removed.
8. Reinstall your footpegs with the new hardware provided.
6. Go for a Ride!!!

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We STRONGLY recommend blue (medium) threadlocker be used on all threads.
- On forwards your weight distribution on the bike is different. Be aware of how this will affect your handling of the bike.
- It is important that your pegs fold-up only when you want them to. That is the purpose of the spring-washer, to hold them tight in the "up" or "down" position. If your peg is not tight upon installation, use a pair of pliers to increase the amount of curve in your spring washer. (see picture below-it does not take much)



www.DKCustomProducts.com