



## *Bar-End Mirror*

### **INSTRUCTIONS**

(Please read entire sheet before beginning install)

#### **Parts included:**

1 Bar-End Mirror

#### **Installation Steps:**

The Bar-End Mirror is mounted into the hole at the end of the handlebars. If you are doing both sides, do the left side first. It is easier and will give you a little experience before doing the throttle side.

#### **Instructions:**

1. If you have rubber grips, the end of the grip needs to have a hole in it the size of the expandable rubber mount on the mirror ( 3/4 " in diameter). This can be accomplished with a utility knife.

If you have end-caps (like on the ISO grips) the end cap needs to be removed. If the hole in the end of the grip is smaller than (3/4 " in diameter) it will need to be enlarged. This can be done with a file or dremel.

2. Once the end of the handlebar is exposed, slip the mirror into the end of the handlebar and tighten it down.

3. Adjust the mirror to your liking.

4. When installing the throttle side mirror, make sure there is space left between the mirror mount and the throttle grip, allowing for unimpeded movement of the throttle.

**General Notes:**

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- **On the throttle side, make SURE that the throttle is able to move freely WITHOUT interference from the mirror. This is imperative for safe operation.**
- On Throttle-by-Wire bikes, this mirror cannot be installed on the right side.

Caution:: Your mirror(s) is now in a different position. Make sure that you are able to see behind you, and take time in getting used to the new location of your mirror(s) The user shall assume all risk and liability of regulations and any incurred financial obligations due to vehicle inspections.

[www.DKCustomProducts.com](http://www.DKCustomProducts.com)