



*Sportster Custom & Roadster
Horn Bracket
Made in The USA!*

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

1 Horn Bracket

Install Steps:

1. Locate the two bolts in between the downtubes (these are pointed up and at the top of the downtubes and can be accessed behind the front fender, in front of the front cylinder)
They are used to secure the upper front stabilizer link.
2. Remove these two bolts..
3. Place Horn Bracket with the longer side closest to the front cylinder and the shorter side with the two holes lined up with the holes from the bolts you just removed.
4. Reinstall the bolts you just removed, securing the horn bracket to the frame between the downtubes. Remember to use blue (medium strength) threadlocker. Tighten to 25-35 ft-lbs
5. You are now ready to install your DK Custom Horn using the one (lower of the three) hole in the horn bracket. If you have purchased a Harley Sportster horn, then all three holes can be used to secure the horn to the horn bracket.

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.

www.DKCustomProducts.com.