



*2014 SPORTSTER
LEFT SIDE FOOT PEG EXTENSION KIT
Made in the USA!*

INSTRUCTIONS

(Please read the entire sheet before beginning install)

Parts included:

- 2 Spacers
- 2 Grade 8 Bolts

Installation Steps:

1. Remove the passenger peg from the peg mount on the left side.
2. Remove the two allen bolts holding passenger peg mount on the left side.
3. Place spacers between the foot peg mount and the frame, using the new grade 8 bolts tighten to factory torque specifications. This is generally to 45-50 ft-lbs.
4. On 2014-Up Sportsters HD newly re-designed rear brake system does not allow adjustment of the right side passenger peg
6. Reinstall the foot peg on the repositioned peg mount.
7. Take your passenger for a Ride!

***Fitment Notes:**

The 1" & 1.5" Peg Extension will fit all 2014 Sportsters. We do not make longer ones due to weight/strength limitations of the bolts holding the mount.

Not only will this extension give the passenger a bit more room, but will also give some room for swingarm "solo" bags.

General Notes:

- The riders & passengers safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- Use Blue (medium) threadlocker on all threads.

www.DKCustomProducts.com