



## *Classic Retro Style Chrome Shift Peg*

*Fits All Harley's & Most other Motorcycles*

### **INSTRUCTIONS**

#### **Parts included:**

1 Retro Style Shift Peg

#### **Installation Steps:**

1. Remove existing shift peg
2. Install your new Shift Peg by threading it into the stock lever. Please make sure to use thread-locker and allow it time to set-up.
3. Go for a ride!

#### **General Notes:**

- The riders safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.
- This peg can also be used as a brake pedal. This will generally require cutting off existing brake pedal and tapping brake lever for bolt. Alternatively a hole can be drilled and a longer bolt and nut can be used to secure the new brake pedal.

[www.DKCustomProducts.com](http://www.DKCustomProducts.com)