



Milwaukee-Eight (M8)

587 AIR CLEANER SYSTEM and AIR CLEANER KIT

MADE IN THE USA!!

The following are instructions for both the Complete Air Cleaner System AND the Air Cleaner Kit. You only need to read the part for your application.

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included in Air Cleaner Kit:

- 1- Air Cleaner Backplate
- 1- Backplate Spacer
- 1- Air Cleaner Cover (of your choice)
- 1- K&N Air Filter
- 1- Nylon Washer
- 1- Acorn Nut W/ Stud (polished S/S and brass)
- 2- Gaskets
- 1- Set of 3M double sided tape to secure emblem (If applicable)
- 4- 1/4"-20 x 1" S/S BHCS
- 4- 1/2" S/S "an" washers (Not used in all applications.)

Installation Steps for Air Cleaner Kit:

1. Remove your air cleaner & air cleaner backplate.
2. Mount the Air Cleaner Backplate to the throttle body with the backplate spacer between the backplate and throttle body. A gasket is used on both sides of the backplate spacer. Use three of the four 1" bolts to secure in place. **See Note Below...Thread locker MUST be used!**
3. Place your K&N Air Filter on the Air Cleaner Backplate and secure using your assembled (If applicable, see notes below.) Air Cleaner Cover, using the supplied brass or S/S acorn nut with stud, you may choose to use the remaining 1" bolt instead.

Note: When performing the step above make sure the filter is seated flush against the backplate. You may need to gently twist while getting the filter to seat. Not doing so could damage the filter or not create a proper seal.

Parts included in Complete Air Cleaner System:

- 1- Air Cleaner Backplate
- 1- Backplate Spacer
- 1- Air Cleaner Cover (of your choice)
- 1- K&N Air Filter
- 1- Nylon Washer
- 1- Acorn Nut W/ Stud (polished S/S and brass)
- 2- Gaskets
- 1- Set of 3M double sided tape to secure emblem (If applicable)
- 4- 1/4"-20 x 1" S/S BHCS
- 4- 1/2" S/S "an" washers (Not used in all applications.)
- 1- External Breather System

Install Steps for Complete Air Cleaner System:

1. Follow same installation instructions as above with the addition of following the instructions for the External Breather System of your choice.

Assembly of Air Cleaner Cover (If applicable):

* The emblem is supplied with double sided adhesive for securing the emblem to the cover plate. Simply remove the backing of the double sided adhesive and carefully place the emblem to the cover plate, lining up the center hole in the emblem to the center hole in the cover plate. This insures that there are no air leaks and that there will be no rattling.

* If you have a Polished Stainless Steel Face Plate Cover, it was shipped to you with a protective film on it. Remove the film prior to installation.

Important Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- If your Breather Bolt for your External Breather System is touching the Air Cleaner Backplate, you can use a couple of extra gaskets to space the backplate out far enough for clearance.
- Torque specs. for the Acorn Nut in the center of the metal covers is 36-60 **INCH**-lbs.
- **Blue Thread locker (medium) MUST be used on all threads. Not doing so risks serious damage to your engine. Not using Thread Locker could result in death or serious injury.**

Caution: For Racing Vehicle Use Only.

Note: This product is not for use on roads or vehicles subject to emission control requirements and is not legal for use or installation on motor vehicles operated on public highways in the State of California or other States where similar emission and decibel regulation laws may apply. The user shall determine suitability of this product for his or her use. The user shall assume all risk and liability of regulations and any incurred financial obligations due to vehicle inspections or emissions tests.

www.DKCustomProducts.com