



TRANSPARENT COVER INSTRUCTIONS

MADE IN THE USA!!

These instructions are CRITICAL to read and follow. It is easy to ruin your New Transparent Cover with an incorrect installation.

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1- Transparent Cover (with a protective covering)
- 3- Rubber Washers
- 1- Metal Washer

Installation Steps for Transparent Cover:

1. Carefully remove the protective covering from both sides of the cover. This can be tricky, if only the outer layer starts coming off, begin in a new spot. Peeling it off slowly has best results. Do NOT use anything that may scratch the surface.
2. The side of the cover with the recessed cut goes Toward the engine..
3. After your stud is installed in the back plate, place TWO of the rubber washers in the recessed area of the cover. Slide the cover onto the stud. (the hole in the cover and rubber washers are oversized to allow you to line up the edges of the cover with the edges of the filter element)
4. The Third rubber washer goes on the outside of the cover, followed by the metal washer, and then the nylon washer and Acorn nut that came with your Air Cleaner.
5. **It is imperative to NOT OVER TIGHTEN the Acorn nut. It only requires 18-24 INCH-lbs of torque.** Over Tightening will result in stress fractures in the cover.

If you do not have an inch-lbs torque wrench, the following is a way to tighten safely.

Put a light film of oil on the outermost rubber edge of the filter element that the cover seals up against.

Very slowly and carefully tighten (by hand-with or without a wrench) the acorn nut until you see the oil between the filter element rubber and the clear cover touch/**seal**. Most people can tighten the acorn nut by hand to in excess of 24 inch-lbs, so proceed carefully.

At no point should the Transparent Cover touch any metal. The two rubber washers will not compress enough at less than 25 inch-lbs for the cover to touch the back plate crossmember.

Installing Emblem (If applicable):

* The emblem is supplied with double sided adhesive for securing the emblem to the cover plate. Simply remove the backing of the double sided adhesive and carefully place the emblem to the cover plate, lining up the center hole in the emblem to the center hole in the cover plate. This insures that there are no air leaks and that there will be no rattling.

General Notes:

With the Transparent Cover a whole new opportunity for personalization exists. You can paint, engrave, use decals, and whatever else you can imagine to the backplate that is now visible through the cover. You can also apply paint or stickers to the actual cover.

Important Notes:

- The riders safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- **Blue Thread locker (medium) MUST be used on all threads. Not doing so risks serious damage to your engine. Not using Thread Locker could result in death or serious injury.**
- **Torque Values are in Inch-lbs (Not ft-lbs)**
- Care of the Transparent Cover: Use only mild detergents, with NO abrasives, along with a soft cotton cloth or microfiber.