



*PLUG-N-PLAY
COIL RELOCATION KIT
Dyna Twin Cam
Hand-Crafted in the USA!*

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1 Coil Relocation Bracket
- 1 Coil Cover Bracket
- 1 Plug-N-Play Coil Wiring Harness Extension
- 2 Coil Bolts (2.5") with washers, lock-washers, and nuts.***
- 1 Coil Cover Mounting Bolt
- 4 Heavy Duty Zip Ties

***Some Models will require use of the factory Coil bolts instead of the supplied bolts.

Installation Steps:

1. Remove Main Fuse OR disconnect battery before proceeding.
2. Unplug wires from stock cowbell horn and remove horn and horn cover from factory mounting point. (Leaving rubber mounted stud in place.) Set the nut and washer aside they will be reused.
3. Remove both plug wires from the coil.
- 4a. On some models the coil cover is held on by the bolts that actually hold the coil to the factory mounting bracket (some have no cover at all). If this describes your bike simply remove

those two bolts and skip steps 4b, 6, 7, and 8.

4b. Remove small bolt from bottom of coil cover, then carefully remove coil cover from coil. (On one side the coil cover is held on by the bolt you just removed, on the other side it is held in place by a slotted tension retainer.)

5. Unplug coil harness connector from the coil

6. Remove the two bolts securing the coil to the stock mounting bracket.

7. Place the 2 coil bolts supplied through the coil (some Models use the longer factory bolts which you can reuse at this time), coil cover bracket, and coil relocation bracket. Then hand tighten the lock-washers and nuts at this point. (If you choose to run your coil without the factory cover you do not need to use the coil cover bracket in this step and can skip step 8.)

8. Place the coil cover over the coil. Once the cover is in place, align the spark plug wire terminals on the coil to be centered in the cover holes. (By doing this you have aligned the brackets to the place where they need to be tightened down.) Then gently remove the coil cover from the coil assembly and tightly secure the coil, coil cover bracket, and coil relocation bracket with the supplied hardware.

9. Plug in the supplied Plug-N-Play Coil Wiring Harness Extension to the plug previously removed from the coil.

10. Mount the coil relocation bracket with coil and cover installed onto the rubber mounted stud reusing the washer and nut you set aside in step 2.

11. Connect the coil harness connector to the coil. Use supplied zip ties to hide the wiring harness.

12. If your Coil Relocation Kit came with plug wires, install them at this time. If you did not get plug wires with your kit, reinstall your factory plug wires.

13. If you purchased a Horn Relocation Kit w/ Horn, install it now.

14. Replace Main Fuse OR reconnect the battery and go for a ride!

General Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.
- We recommend riding safely and complying with your local laws. Please install a horn before riding.

www.DKCustomProducts.com

Patented