



## *Trap Moto Footpegs*

For All Applications Except M8 Softails

### **INSTRUCTIONS**

(Please read entire sheet before beginning install)

#### **Parts included:**

- 1 Pair of Footpegs
- 2 Retaining Rings

#### **Installation Steps:**

1. Remove retaining ring (c-clip) from clevis pin\*
2. Remove clevis pin and pull out foot peg from clevis bracket, being careful to catch the spring washer.
3. Install new foot peg with spring washer at the same time. Make sure spring washer is positioned with the square edge toward the bike.
4. Align holes and push clevis pin from the top down, secure it with the new retaining ring supplied.
5. Using an allen wrench, make sure the peg is at the angle most comfortable for you, and then tighten into place
6. Repeat procedure for the other foot peg.

\* In some instances there may be a bolt and nut instead of a pin and retaining ring.

You are Ready to Ride!

**General Notes:**

- The riders' safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- We recommend blue thread locker be used on all threads.
- It is important that your pegs fold-up only when you want them to. That is the purpose of the spring-washer, to hold them tight in the "up" or "down" position. If your peg is not tight upon installation, use a pair of pliers to increase the amount of curve in your spring washer. (see picture below-it does not take much)



[www.DKCustomProducts.com](http://www.DKCustomProducts.com)