



PREMIUM

ECM Fender Cover For Solo Seat

Made in The USA!

2007-2009 Sportster Rear Fender

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

- 1- Fender Cover
- 1- Set of Velcro Attachments

Installation Steps:

1. Always Remove Main Fuse OR disconnect battery when working on your motorcycle.
2. With your Solo Seat installed on your bike, and your ECM removed from the rear fender, (2007-2009 models only) place the fender cover over the hole in your fender and make note of where you would like it to sit.
3. After you know where you would like it to sit, Thoroughly clean the fender of any dirt, oil, or other debris so that the adhesive on the velcro attachments have a clean surface to stick to.
4. With some good scissors, cut the velcro attachments to match the velcro on the back of the fender cover AND where you want it to sit on the fender. Now attach the velcro attachments to the Fender Cover.
5. Remove the protective film from the velcro attachments to expose the adhesive.
6. With Velcro attachments attached and adhesive backing exposed, place the Fender Cover into position and press down firmly where the adhesive makes contact with the frame.
7. Wait a few minutes for adhesive to cure and your Fender Cover is installed.

www.DKCustomProducts.com