

PREMIUM Solo Seat Frame Cover *Made in The USA!*

INSTRUCTIONS

(Please read entire sheet before beginning install)

Parts included:

Frame Cover
Set of Velcro Attachments

Installation Steps:

1. Always Remove Main Fuse OR disconnect battery when working on your motorcycle.

2. With your Solo Seat installed on your bike, place the frame cover under your seat and make note of where you would like it to sit.

3. After you know where you would like it to sit, attach the velcro attachments to the Frame Cover.

4. Thoroughly clean the frame of any dirt, oil, or other debris so that the adhesive on the velcro attachments have a clean surface to stick to.

5. Remove the protective film from the velcro attachments to expose the adhesive.

6. With Velcro attachments attached and adhesive backing exposed, place the Frame Cover into position and press down firmly where the adhesive makes contact with the frame.

7. Wait a few minutes for adhesive to cure and your Frame Cover is installed.

www.DKCustomProducts.com