

3-D AIR CLEANER COVER

MADE IN THE USA!!

INSTRUCTIONS

(Please read all instructions before beginning install)

Parts included:

- 1- Air Cleaner Inner Cover (Silver Flake)
- 1- Air Cleaner Front Plate (With Cut-Out Design)
- 1- Inner Cover Mounting Bolt (1/4 -20) with Washer
- 2- Front Plate Mounting Bolts (10-24)
- 14- Small Washers for Front Plate

Installation Steps for Cyclone Cover:

- 1. With the air cleaner backplate installed and filter in place, mount your 3-D Air Cleaner Inner Cover using the Inner Cover mounting bolt. Tighten to 18-24 inch/lbs. Be sure the filter is centered when tightening down. (USE MEDIUM THREAD LOCKER)
- 2. Place one small washer on one front plate mounting bolt and place the bolt through the front of the Air Cleaner Front Plate then place six small washers on the opposite side of the plate. Just barely start the threads into the Inner Cover at this time. (USE MEDIUM THREAD LOCKER)
- 3. Place one small washer on the remaining front plate mounting bolt and with the Inner cover pivoted to the side stick the bolt through the opposite hole on the Front Plate. Place six small washers on the back side of the cover.
- 4. Being sure the small washers stay in place, pivot the front plate into place and start the bolt into the Inner cover. (USE MEDIUM THREAD LOCKER)
- 5. You may now tighten down the Front Plate Mounting Bolts to 18-24 inch/lbs and GO FOR A RIDE!!!!!

Important Notes:

- The rider's safety depends on the correct installation of this kit. Please do not attempt if you have any doubts of your ability to install.
- Blue Thread locker (medium) MUST be used on all threads. Not doing so risks serious damage to your engine. Not using Thread Locker could result in death or serious injury.
- Torque Values are in Inch-lbs (Not ft-lbs)
- We are NOT responsible for any damage done to you or your bike as a result of the installation of this cover.

www.DKCustomProducts.com

Note: The user shall determine suitability of this product for his or her use. The user shall assume all risk for damage and liability to the vehicle and for compliance of any regulations and any incurred financial obligations due to vehicle inspections.