

Passing/Driving LED Bulbs

Parts included:

2- Led Bulbs

Installation Instructions:

- 1. Remove the outer ring from the passing/driving light housing.
- 2. Remove the bulb housing from the assembly.
- 3. Unplug and remove the stock bulb.
- 4. Install your new LED bulb being careful not to touch the yellow diodes.
- 5. Reinstall your bulb housing into the assembly the same way it was removed.
- 6. Reinstall the outer ring and go for a Ride!!!!

Important Notes:

- The rider's safety depends on the correct installation of this LED bulb Please do not attempt if you have any doubts of your ability to install.
- When wiring this headlight to your bike, make sure to make good connections.
- We STRONGLY recommend using blue (medium) thread locker on all threads.

www.DKCustomProducts.com